

---

# **APPENDIX 6**

## **Strategies For Characterizing Subsurface Releases of Gasoline Containing MTBE**

API Publication number 4699, February 2000

### **TABLE OF CONTENTS**

<b>EXECUTIVE SUMMARY</b>	<b>ES-1</b>
<b>Section 1 INTRODUCTION</b>	<b>1-1</b>
<b>Section 2 MTBE AND OTHER FUEL OXYGENATES</b>	<b>2-1</b>
<b>2.1 GENERAL PROPERTIES</b>	<b>2-1</b>
<b>2.2 USE OF OXYGENATES IN GASOLINE</b>	<b>2-2</b>
<b>2.3 ENVIRONMENTAL ISSUES</b>	<b>2-3</b>
2.3.1 Sources	2-3
2.3.2 Oxygenates in Soil Vapor	2-4
2.3.3 Oxygenates in Soil	2-5
2.3.4 Oxygenates in Groundwater	2-5
<b>2.4 ANALYTICAL AND REGULATORY ISSUES</b>	<b>2-6</b>
2.4.1 Analytical Methods	2-6
2.4.2 Environmental Standards	2-7
<b>Section 3 RISK-INFORMED DECISION-MAKING AND MTBE ASSESSMENT</b>	<b>3-1</b>
<b>3.1 RISK-BASED DECISION-MAKING</b>	<b>3-1</b>
3.1.1 Introduction	3-1
3.1.2 Conceptual Site Model	3-2
<b>3.2 RISK FACTORS</b>	<b>3-4</b>
3.2.1 Risk Factors Related to Receptors	3-4
3.2.2 Risk Factors Related to Pathways	3-5
3.2.3 Risk Factors Related to Sources	3-6
<b>3.3 RISK-INFORMED ASSESSMENT DECISION FRAMEWORK</b>	<b>3-7</b>
3.3.1 Receptor Characterization Tasks	3-8
3.3.2 Pathway Characterization Tasks.	3-16
3.3.3 Source Characterization Tasks	3-29
3.3.4 Verification Monitoring	3-36
<b>3.4 CONFIRMATION OF CONCEPTUAL SITE MODEL AND</b>	
<b>EXAMPLE LEVELS OF ASSESSMENT</b>	<b>3-37</b>

<b>Section 4 MTBE ASSESSMENT AND MONITORING</b>	<b>4-1</b>
<b>4.1 OBJECTIVES</b>	<b>4-1</b>
<b>4.2 ETHER OXYGENATE ASSESSMENT VS. HYDROCARBON ASSESSMENT</b>	<b>4-1</b>
4.2.1 Sources	4-1
4.2.2 Plume Geometry	4-2
4.2.3 Biodegradation	4-4
4.2.4 Sample Media Biases	4-4
<b>4.3 EXPEDITED ASSESSMENT</b>	<b>4-5</b>
4.3.1 Conventional Site Assessments	4-5
4.3.2 Expedited Site Assessments	4-6
<b>4.4 INNOVATIVE TECHNOLOGIES</b>	<b>4-7</b>
4.4.1 Direct Push Sampling Technologies	4-12
4.4.2 Small-Diameter Monitoring Wells	4-25
<b>REFERENCES</b>	<b>R-1</b>
<b>Appendix A STRUCTURE AND PROPERTIES OF OXYGENATES</b>	<b>A-1</b>
<b>A.1 CHEMICAL STRUCTURE</b>	<b>A-1</b>
<b>A.2 CHEMICAL PROPERTIES.</b>	<b>A-2</b>
A.2.1 Water Solubility	A-2
A.2.2 Solids-Water Partition Coefficient	A-5
A.2.3 Vapor Pressure	A-6
A.2.4 Henry's Law Constant	A-8
A.2.5 Retardation in Groundwater	A-8
A.2.6 Retardation in the Vadose Zone	A-10
A.2.7 Biodegradability	A-10
A.2.8 Human Toxicity	A-11
A.2.9 Ecological Toxicity	A-12
A.2.10 Taste and Odor Thresholds in Drinking Water	A-13
<b>Appendix B SUMMARY OF TIERED RISK-BASED DECISION MAKING</b>	<b>B-1</b>
<b>B.1 RISK-BASED DECISION FRAMEWORK</b>	<b>B-1</b>
<b>B.2 THE TIERED APPROACH TO RISK EVALUATION AND CORRECTIVE ACTION</b>	<b>B-2</b>
<b>B.3 NON-RISK CONSIDERATIONS AND POLICY CONSTRAINTS FIGURES</b>	<b>B-4</b>
3-1—Example of an Exposure Pathway Flowchart.	3-3
3-2—Plunging MTBE Plume in a Regional Groundwater Recharge Area	3-18
3-3—Rising MTBE Plume in a Regional Groundwater Discharge Area	3-19
3-4—Plunging MTBE Plume Caused by Groundwater Pumping	3-20
3-5—MTBE Plume Captured by Supply Well	3-20
3-6—Defining the Capture Zone of the Supply Well May Identify Sources	3-21
3-7—Using a Well Cluster to Evaluate Contaminant Migration Controlled by Geologic Stratification	3-22

3-8—Thick Aquitards Can Protect Deeper Groundwater Supplies, Even When Downward Hydraulic Gradients Exist.	3-24
3-9—MTBE Plume Migrating Through a Leaky Aquitard	3-24
3-10—Plume Delineation Affected by Pumping Patterns	3-27
3-11—Defining an Anaerobic “Shadow” Can Help Define the Trajectory of An MTBE Plume	3-28
3-12—Example MTBE Source Conditions	3-32
3-13—Missing the Plume by Collecting a Single-Depth Groundwater Sample Below the Zone of Contamination	3-33
4-1—Examples of Non-Sealed Soil Samplers and Sample Barrels	4-14
4-2—Example of a Piston Soil Sampler	4-15
4-3—Examples of Soil Gas Sampling Tools	4-17
4-4—Example of a Sealed Screen Groundwater Sampling Tool	4-19
4-5—Collecting a Groundwater Sample Ahead of a Hollow Stem Auger Using a Sealed Screen Direct-Push Tool	4-20
4-6—Example of a Groundwater Profiler	4-21
4-7—The SimulProbe® Sampling System	4-24
4-8—Single-Interval Monitoring Well Installed With Direct-Push Equipment	4-26
4-9—Direct-Push Multi-Level Monitoring System	4-28
4-10—Multi-Level Monitoring Well used to Define Distribution of Dissolved MTBE in a Stratified Alluvial Aquifer, Vandenburg AFB, California	4-29
A-1—Chemical Structure of Benzene, Ethanol, and MTBE	A-1
A-2—Comparison of Equilibrium Partitioning for Benzene and MTBE	A-6

## **TABLES**

3-1—Receptor Identification Tasks	3-9
3-2—Initial Level of Assessment Based on Basin Groundwater Usage and Proximity to Potable-Use Wells	3-11
3-3—Characterization Tasks and Level of Assessment	3-13
3-4—Example Conditions Associated with Different Levels of Assessment	3-39
4-1—Innovative Technologies for MTBE Assessment and Monitoring	4-9
A-1—Comparison of Physical Properties of BTEX and Oxygenates	A-3